

Pre-wired Handlebar Switches instructions



White Wire - Left Indicator

Green Wire – Right Indicator

Brown Wire – Horn

Yellow Wire – High Beam

Braided Wire / Shield – GND/Negative



Brown Wire – Stop Button

White Wire – Start Button

Braided Wire / Shield – GND/Negative

Green Wire – Not connected, you can use it for the hand brakeswitch.

Instructions: www.elektronikbox.de